



Handling instructions
Shrink fit MQL



Coolant tube

Not included, available as accessory




HSK-A/C/T sizes	Ordering code	Key	Torque (Nm)
63	5692 022-04	5680 094-04	20
100	5692 022-16	5680 094-06	30

Balancing screws are available to order as accessories.
Ordering code: 5514 100-01



Coolant screws for MQL

Not included, available as accessory



Solid holder	Shaft Size mm	Screw length L mm (inch)
5692 039-01	6	34 (1.339)
5692 039-02	6	17 (.669)
5692 039-03	8	34 (1.339)
5692 039-04	8	18 (.709)
5692 039-05	10	35 (1.378)
5692 039-06	10	18 (.709)
5692 039-07	12	35 (1.378)
5692 039-08	12	18 (.709)
5692 039-09	16	37 (1.457)
5692 039-10	16	22 (.866)
5692 039-11	20	40 (1.575)
5692 039-12	20	23.5 (.925)
5692 039-13	25	27.5 (1.083)
5692 039-14	32	30.5 (1.200)

Head office:
AB Sandvik Coromant
SE-811 81 Sandviken, Sweden
www.sandvik.coromant.com
E-mail: info.coromant@sandvik.com

92048

© AB Sandvik Coromant 2017.01

